## MyNK50V: Jammed caddy-loader or it loads more than one disc at a time

• Some discs may be sticky and may be stuck together. Loose the discs before loading them into the loader.

• Reduce the quantity of discs in the Loader. Try 15 to 20 discs first.

• Use discs of the same brand and do not mix various disc brands.

• Remove all discs from the loader. Carefully load only one disc into the caddy-loader and assure it is firmly resting on the three wheels. You may then gradually load additional discs on top of the first disc, until the loader is full.

• Try discs of different brands. Some discs are out-of-specification in diameter or thickness, or even distorted.

Unique solution ID: #1083 Author: Acronova Tech Support Last update: 2010-11-02 08:56

Page 1/1