

MyNK50V: NK50V shows error by flashing-red indicator

â€¢ Remove all discs from the caddy-loader. Make sure no disc left in disc caddy.

â€¢ Make sure that disc caddy doesnâ€™t get stuck between NK50V and Epson printer.

â€¢ Reinstall NK50V (refer to the Hardware Installation section).

Unique solution ID: #1085

Author: Acronova Tech Support

Last update: 2010-11-02 08:55