

MultiNK50V: NK50V does not load disc and Epson Printer Status Monitor Windows shows "CD/DVD tray not set correctly"•

• It takes a few seconds before NK50V starts loading disc. Wait patiently.

• Check the caddy-loader and make sure discs are correctly loaded.

• Check MultiNK50V Main Menu and make sure NK50V is ready.

• Avoid direct sunlight.

Unique solution ID: #1086

Author: Acronova Tech Support

Last update: 2010-11-02 09:09