

MultiNK50V: Epson printer shows error on indicators or error status window

â€¢ Go to MultiNK50V main menu. Click the Stop All NK50V button. Turn off Epson printer; wait for one minute and turn it on.

â€¢ Detach NK50V from Epson printer. Test the printer itself to ensure proper operation.

â€¢ Refer to Epson printer manual for error message and troubleshooting tips.

Unique solution ID: #1091

Author: Acronova Tech Support

Last update: 2010-11-02 09:02