

QQboxx : Why does QQBoxx fail the initialization of auto-duplicator?

Reason:

The auto-duplicator is off.

Recommendation:

Always make sure the auto-duplicator is power-on before starting QQBoxx. If it has been power-off, close QQBoxx, turn on the power of the auto-loader, then launch QQBoxx again.

Check the device driver to see if it is successfully installed.

Â

Unique solution ID: #1050

Author: Acronova Tech Support

Last update: 2009-11-24 07:04