# PC-Connected: Initialization fails after launching the software but the unit is turned on.

### Reason 1:

Problem with the USB connection between PC and the unit.

### **Recommendation 1:**

- 1. Check USB connection
- 2. Change USB cable
- 3. Check if USB slot is USB 2.0 Hi-Speed spec

Â

## Reason 2:

SATA USB bridge board is defected.

### **Recommendation 2:**

- 1. Turn on the devide manager to see if the disc autoloader and the USB RW drive are online. If not, there is a problem with the USB connection. Check if the USB cable, USB slot of the unit and PC's USB slot are functioniong.
- 2. Turn on the devide manager to see if the disc autoloader and the USB RW drive are on-line. If the autoloader is online but the RW drive isn't, reboot the PC and the unit and try again.
- 3. If the problem still exist after several try-outs, contact your supplier.

Â

Unique solution ID: #1033 Author: Acronova Tech Support Last update: 2009-11-24 04:46