MyNK50V: NK50V does not load disc and Epson Printer Status Monitor Windows shows â€œCD/DVD tray not set correctlyâ€•

Â â€¢ It takes a few seconds before NK50V starts loading disc. Wait patiently.

Â â€¢ Check the caddy-loader and make sure discs are correctly loaded.

Â â€¢ Check MyNK50V Main Menu and make sure NK50V is ready.

Â â€¢ Avoid direct sunlight.

Unique solution ID: #1075
Author: Acronova Tech Support
Last update: 2010-11-02 07:03

(c) 2024 John Doe <support@acronova.com>