

MyNK50V: Epson printer shows error on indicators or error status window

â€¢ Go to MyNK50V main menu. Click the Stop NK50V button. Turn off Epson printer; wait for one minute and turn it on.

â€¢ Detach NK50V from Epson printer. Test the printer itself to ensure proper operation.

â€¢ Refer to Epson printer manual for error message and troubleshooting tips.

Â

Unique solution ID: #1080

Author: Acronova Tech Support

Last update: 2010-11-02 08:03