

MyNK50V: Discs do not slide out of the output ramp from NK50V

• If the disc stays on the ramp, clean the ramp surface.

• If the disc gets stuck in disc caddy, clean the caddy's sliding surface or replace with a new caddy. Additional caddies are available for purchasing.

Unique solution ID: #1082

Author: Acronova Tech Support

Last update: 2010-11-02 08:14