

## *MyNK50V: NK50V shows error by flashing-red indicator*

- Remove all discs from the caddy-loader. Make sure no disc left in disc caddy.
- Make sure that disc caddy doesn't get stuck between NK50V and Epson printer.
- Reinstall NK50V (refer to the Hardware Installation section).

*Unique solution ID: #1085*

*Author: Acronova Tech Support*

*Last update: 2010-11-02 08:55*