

QQboxx : What should I do if the auto-loader does not run during a job?

Recommendation:

You can either click on "Retry", or click on "Cancel" to stop the job. If the loader still hangs, try rebooting the auto-duplicator.

Unique solution ID: #1051

Author: Acronova Tech Support

Last update: 2009-11-24 07:09