Nimbie Standalone: When turning on the unit, the LED light is off, the fan is on but the unit does not initialize.

Reason:

No electricity to the mainboard or the mainboard is damaged.

Recommendation:

Please contact your supplier.

Unique solution ID: #1023
Author: Acronova Tech Support
Last update: 2009-11-24 04:44

(c) 2024 John Doe <support@acronova.com>
URL: http://disc.acronova.com/kb/index.php?action=artikel&cat=2&id=24&artlang=en