

Nimble USB: All discs are ejected to the failed disc bin.

Reason: LightScribe discs were not placed label side down.

Â

Recommendation:

Check if all LightScribe discs are placed with the label side down.

Unique solution ID: #1017

Author: Acronova Tech Support

Last update: 2009-11-26 03:52