## Nimble USB: When labeling the first disc or after a number of discs, the program does not respond and LS\_Dialog does not appear.

**Reason:** When LightScribe Windows Public SDK (SDK) V.1.18 encounters a disc that cannot be identified as a LightScribe disc, SDK will shut down automatically which can stop the program from responding or a LS\_Dialog.exe errow window will appear.

Â

## **Recommendation:**

Check if LightScribe System Software (LSS) and LightScribe Windows Public SDK (SDK) has been upgraded to V1.18. If it has been upgraded, remove LSS and SDK and reinstall LSS and SDk V1.16 included in the installation disc.

Unique solution ID: #1022 Author: admin2 Last update: 2009-11-26 03:48