

MultiNK50V: MultiNK50V can't detect or activate NK50V

• Make sure Epson printer is ready (the LED indicator lights up steady-green).

• Make sure NK50V is ready (the LED indicator lights up steady-green).

• Make sure USB cables are correctly connected among NK50V, Epson printer, and PC.

• Make sure the caddy-loader is attached onto NK50V and the loader cable is correctly connected.

• Remove NK50V from Epson printer. Manually print a few discs to make sure printing software is successfully installed.

• Remove NK50V from Epson printer. Refer to Replace Disc Caddy section to make sure that NK50V and its device driver are successfully installed.

Unique solution ID: #1090

Author: Acronova Tech Support

Last update: 2010-11-02 09:05